

PB-68 (Grey)

Panic Button



Emergency panic button is ideal for activating or triggering alarm to request for help for homes and offices.

During emergency, press the red button which will trigger output alarm and it is permanently depress until a reset key is slot in to de-activate. Once key is slot in and turn, the spring internally will spring back and the red button setting the alarm is de-activated. Reset is used for easy arm and disarm operations.

- ☐ Housing: Hard Plastic
- ☐ Color: Grey with Red Button
- ☐ Micro Switch Operation
- ☐ Switch withstood-voltage:
- ☐ Operating Voltage: 12V DC
- ☐ Load Current: 300mA
- ☐ Measurements: 4.5 x 4.5 x 3.7 cm
- ☐ Flush Mount, Small
- ☐ Indoor Use
- ☐ 1 Reset Key; On-Off Mode
- ☐ Weight: 33gm including key