

TS-01

Tamper Switch



- ☐ Tamper switch
- □ NC (Normally close) Contact when depressed
- ☐ With cables and lug
- ☐ For usage on:
 - Alarm control panel
 - Siren box